



# Hollister-Whitney Elevator Corporation

#1 Hollister-Whitney Parkway  
Quincy, IL 62305  
Phone: 217-222-0466

Fax: 217-222-0493  
e-mail: info@hollisterwhitney.com  
www.hollisterwhitney.com

## LUBRICATION INSTRUCTIONS FOR H-W GOVERNORS AND TENSION WEIGHTS

The Latest Version of this E-Document can be Found at:

<http://www.hollisterwhitney.com/#tech-support>

BEARING GREASE: POLYREX EP2 by EXXON

BUSHING LUBRICATION: SAE 30Wt Non-Detergent Oil

General Note Concerning Needle and Ball Bearings – If a Grease Zerk is Provided, Grease Needs to be Checked and Maintained

1) Fillable Sheave or Shaft Bearings:

- Governor Models #201, #205, #206, #207 (Dead Shaft), #208, #209, #210
- Tension Weight Models #191, #192, #193, #194

The Bearings and Bearing Cavity of the above are completely filled with lubrication at the H-W plant. Check at least Yearly and re-lubricate as necessary at the Zerk Fitting until Cavity is filled.

Zerk Locations:

- |   |                       |
|---|-----------------------|
| • Governor Models #201, #205, #207 (Dead Shaft), #208 | Sheave Hub            |
| • Governor Models #206, #209, #210                    | Shaft Housing on Base |
| • Tension Weight Models #191, #192, #193, #194        | Sheave Hub            |

2) Sealed Sheave Bearings:

- Governor Models #202, #207 (Live Shaft)

These Governor Models have Sealed Bearings in the Sheave/Shaft Assembly and do not require Additional Lubrication.

3) Governor YOKE ASSEMBLY Bushings:

- Governor Live Shaft Models: #202, #206, #207, #209, #210

It may be Necessary to apply a few Drops of Lubricant (Oil) as Required to the Live Shaft Governors Listed Above. These Bushings Should be Checked at least every 6 to 8 Months. Note however, that some Environments, including those with Salt Air and/or High Dust Content (such as Fly Ash, Grain or Concrete Dust, Construction Dust), may Severely Shorten this Maintenance Period. Simply add a few Drops of Oil at the front and back of the Yoke Assembly to Maintain Lubrication